

## Product Data Sheet – ULTRA PRIME

### Description

Ultra Prime is water based pigmented acrylic primer. It is a specially formulated pigmented primer, comprising of alkali resistant co-polymer acrylic binder, titanium dioxide pigment, inert quality mineral extenders, proprietary additives and a premium fungicide.

### Uses

Ultra Prime is used as a protective undercoat primer for various masonry substrates and is a system product of the Ultratex Wall-Coating system, it is applied to the substrate to unify the substrate porosity, and it ensures maximum adhesion and provides excellent key and coverage for following texture and topcoats. It substantially upgrades the overall coating system durability & ensures greater system consistency, especially over large areas, by reducing surface absorption of the top coat it helps in controlled drying of the texture and top coats ensuring longer open-time and durable curing of the texture or top coat.



### Features and Benefits

- Easy to apply
- Water based
- Easy & safe clean up
- Excellent durability
- Strong adhesion
- Blocks efflorescence

### Suitable Substrates – when properly prepared

- Cement Render & other rendered surfaces
- Clay and Concrete Brickwork
- Concrete blocks
- Concrete Tilt Panel
- Off-form concrete
- AAC (Autoclaved Aerated Concrete)
- Fibrous Cement Sheeting (Fibro/Blue board)

### Surface Preparation

- Areas not to be coated should be masked and protected
- All surfaces to be coated must be clean, sound, free from contaminants including; oil, mould release, dust, dirt, silicone, mud, grease, salt, efflorescence, animal droppings and any loose or flaking material.
- In case of Concrete Tilt-up or Pre-cast panels ensure and confirm Bond Breaker/mould release agents are present or not, if present use Bond remover to first remove the Bond Breaker before applying Primer

### Application



**Before application ensure surface is cured and dry;**

- Mix thoroughly with power mixer before use
- Ultra Prime is applied using a 10-20mm Nap Roller, roll evenly on surface with slight pressure.

- Can be applied by brush and Airless Spray, Typical Airless Spray set up is: Graco Ultra 500 using 0.017-0.019 spray tips at approx. 1500 psi.
- Apply one coat of UltraPrime evenly and let it dry for minimum 2 hour before top coating.

### Important Information

- Ultra Prime must only be applied in air temperatures between 10°C and 30°C on a dry substrate and must be protected from rain and frost for the first 24 hours or finished work must be protected from rain, frost and severe weather conditions until fully dried.
- Avoid application in full sun or hot, windy conditions.

Packing	Coverage	Application Thickness
15L Plastic Pail	6.5SqM/L 100SqM /Pail	WFT 75-100uM
No. of coats	Generally one coat application	
Application method	10-20 Nap roller 	Roller
Clean Up	 Clean all with water after use	
Appearance	White viscous liquid	
Type	Acrylic copolymer emulsion	
Drying Time(25°C & 50% RH)	Tack Free	Overcoat
	1hrs	2hrs
		Fully Dry
		7 days
Gloss levels	Matt	
Specific Gravity	~ 1.15-1.25	
Thinner	Water – not recommended	
Shelf Life	24 months from date of mfg (sealed)	

### Safety and Handling

**Refer to Material Safety data sheet and warranty document before use**

- Avoid inhalation of the vapour, prolonged skin contact and particularly eye contact
- Wear protective clothing to minimize skin contact and wear goggles where splatter is likely
- Where spills occur, soak up liquid spillage with sand/sawdust and dispose of in a sensible manner. Do not permit run-off to sewer, storm water or open bodies of water.
- Storage: Store away from food and drink and in a safe place

For further information on *Warranty & Limitations or Material Safety Data Sheet* for Ultra Prime, please call (03) 9364 4489 or visit [www.Ultratexvic.com.au](http://www.Ultratexvic.com.au)